



OPTIONAL-SIDE OF  
FENDER MOUNTED  
ARM ASSEMBLY

TOP OF FENDER  
MOUNTED ARM  
ASSEMBLY

**ASSEMBLY INSTRUCTIONS**  
THIS MIRROR UNIT COMES  
FULLY ASSEMBLED FOR  
MOUNTING TO THE FRONT  
FENDER OF YOUR VEHICLE

(2) DIFFERENT WAYS  
ARE SHOWN TO MOUNT  
THE MIRROR ARM. USE  
 $\frac{5}{16}$  DRILL FOR CLEARANCE  
HOLE AFTER MARKING  
THE (3) MOUNTING LOCATIONS  
THE VINYL COATED 3"  
WASHER IS USED FLUSH  
TO THE OUTSIDE OF FENDER  
WHILE THE METAL 3"  
WASHER IS USED FLUSH  
TO THE INSIDE OF FENDER

FOR TOP FENDER MOUNT  
OF MIRROR-(SHOWN ON RIGHT)  
BE SURE SWIVEL BRACKET  
ON MIRROR ARM MOUNTS  
OPPOSITE-(90°) OF THE  
SWIVEL BRACKETS ON BRACES

FOR SIDE FENDER MOUNT  
OF MIRROR-(SHOWN ON LEFT)  
REMOVE SWIVEL BRACKET  
ON MIRROR ARM & ROTATE  
FLATTENED END OF ARM  
BY LOOSENING ADJUST-  
MENT NUT LOCATED ON  
MIRROR ARM. FLATTENED  
END OF ARM MOUNTS  
DIRECTLY ON TO THE  
MOUNTING CUP.

Model #880

**SURE  
SP  
PLUS®**

Nationally Famous Truck Mirrors  
12th and McKinley  
Chicago Heights, IL 60411  
1-800-621-2741

RLD